注意：第一次使用暖風機，可能會出現少量氣味約數分鐘，因本產品在生產時發熱元件帶有一層保護油，此乃正常現象。

NOTE: For first time operation, there may be a slight odor for a few minutes. This is because the Heater has some protective oil on the surface of the heating element.

暖風機可使用機身頂部控制面板操控。

The Heater may be operated by the control panel located on the Heater.

- 將暖風機擺放於穩固的平面上。
- Place the Heater on a stable flat surface.
- 將插頭插入獨立插座，暖風機會嗶聲響起，暖風機進入準備狀態。
- Plug the power plug into an electrical outlet, the Heater will beep, then the Heater is ready to use.
- 開/關：按 鍵，暖風機將以低熱運作，低熱白色指示燈同時亮起，按 鍵可轉換至高熱(紅色指示燈亮起)或風扇 運作。
- ON/OFF : Press the key, the Heater will start operation at Low Heat , white Low Heat indicator will light on. Press the key to set the Heater into High Heat(red indicator light will light on) or Fan .
- 定時設定：使用 鍵連續按下選定3個不同的自動關機時間，分別由0.5/1/2小時，LED顯示屏顯示已選擇的時間。
- TIMER : Press the key repeatedly to set desired auto power off time. There are 3 time intervals, from 0.5/1/2-hour, for auto power off. The LED display indicates the time selected.
- 鎖定功能 : 在待機或工作狀態下，同時按下 及 鍵3秒，控制面板將被鎖上，再次同時按下 及 鍵3秒，鎖定即可解除。
- LOCK: In the standby or working state, Press and hold the and key for 3 seconds, control panel is locked. To release lock function, press and hold the and key simultaneously for 3 seconds.
- 關機 : 如需關機，按 鍵。為使機內溫度下降，關機後的暖風機，風扇將繼續送風30秒，才完全停止運作。
- OFF : To turn the Heater off, press the key. The FAN will work for 30 seconds to cool down the Heater and then turn OFF.

***注意 : 當暖風機發生傾倒時，暖風機會自動停止運作。

***Note : If the Heater topples, The Heater will automatically stop.

解除強制關機 | Disable Mandatory Auto Off

解除4小時強制關機功能 / Disable the 4-hour mandatory shutdown function

為加強使用安全，本暖風機預設4小時強制關機功能。如要解除此功能，請依以下步驟：

In order to enhance the safety of use, this Heater is preset with a forced shutdown function of 4 hours. To disable this feature, please follow the steps below:

- 於接上電源後10秒內同時長按 ⏻ 鍵及定時設置鍵 ◷ 5秒。
- Within 10 seconds after connecting the Heater to the power supply, press and hold the ⏻ key and the timer key ◷ simultaneously for 5 seconds.
- 當聽到咇聲後，定時LED顯示燈會閃爍，4小時自動關機功能已無效。
- A beep will sound, the timer LED indicator will flash, and the 4-hour automatic shutdown function will be disabled.
- 如要恢復4小時自動關機功能，拔除插頭30秒後再重新接上電源。
- To restore the 4-hour automatic shutdown function, Unplug the Heater, wait 30 seconds, and then reconnect it to the power supply.





圖片只供參考，一切以實物為準
The picture is for reference only, the actual product shall prevail.

特殊安全裝置
Safety Features

- 暖風機內置恆溫保護裝置，防止機身過熱。
- A thermal overload protector is built-in to prevent overheating.
- 因為安全起見，機身傾側即會自行停機。
- For safety reasons, the Heater will automatically stop if it tilts.
- 當機內溫度超出限定溫度，暖風機將自動停止操作。需要重新設置才可恢復正常:
- When the Heater overheats, it will be shut off automatically. To RESET the Heater:
  - 拔除插頭，等待30分鐘，讓機內溫度降低。
  - Unplug the Heater and wait for 30 minutes to cool down.
  - 重新插上插頭，讓暖風機正常繼續操作。
  - Turn the Heater on again to resume operation.

清理及維護
Maintenance

警告：不使用本機時，經常保持拔除電源。清理時切勿將此機浸於水或其他液體中。清潔前應確保暖風機處於冷卻狀態。

WARNING: ALWAYS UNPLUG THE POWER CORD BEFORE MOVING OR SERVICING. DO NOT IMMERSE THE HEATER IN WATER! MAKE SURE THE HEATER HAS COMPLETELY COOLED DOWN BEFORE CLEANING.

清理：使用吸塵機毛刷將入風口的塵埃及雜物吸走。機身使用濕潤軟布抹擦清潔。
注意：切勿使用含有腐蝕性的清潔劑或溶液清理此機。

CLEANING: Clean the Air Inlet with the vacuum cleaner's brush attachment on your vacuum cleaner. Wipe the Heater with a soft damp cloth.


CAUTION: Do NOT use gasoline, benzene, thinner, harsh cleaning agents, etc, as they will damage the Heater. NEVER use ALCOHOL or any other SOLVENTS.

儲存：連同使用說明書，把暖風機存放於清涼及乾爽的地方。

STORAGE: Store the Heater in its original box together with this instruction manual in a cool and dry place.

型號 Model Number	FH9519K
電源 Power Supply	220-240V~ 50-60Hz
額定功率 Rated Power	600瓦特/Watts
淨重 Net Weight	870克(gram) (約/Approx.)
產品尺寸 Product Dimension	117(W) x 117(D) x 240(H)mm (約/Approx.)

源澤地圖
Origin Map



辦公時間
10:30am - 12:30pm (星期一至五)
02:30pm - 05:30pm (星期一至五)
10:30am - 12:30pm (星期六)
(星期日及公眾假期休息)

OFFICE HOURS
10:30am - 12:30pm (Mon to Fri)
02:30pm - 05:30pm (Mon to Fri)
10:30am - 12:30pm (Saturday)
(Closed on Sunday and Holiday)

保用

陶 瓷 暖 風 機
Ceramic Fan Heater

origo

產品: 陶瓷暖風機

型號: FH9519K

此產品由購買日期起計算，本公司將根據下列條款及細則，提供一年保養服務(商業用途則為3個月):

1. 於購買後一年內，經本公司技術員判斷為正常運作下損壞之產品，可獲免費維修和/或零件更換。
2. 以下情況不被包括在保養範圍內：
   - 若產品是因為濫用、錯誤使用、疏忽及/或意外而遭致損壞；
   - 未經本公司授權之自行處理、維修及/或改裝；
   - 任何機殼、面蓋、後網、電源線及插頭，以及配件。
3. 需要檢查或維修時，請將產品送往本公司服務中心，並於修理妥當後自行取回。
4. 更換後之任何零件或配件，均屬本公司所有。
5. 本保養服務只適用於香港特別行政區。
6. 顧客必須同時出示零售商之正式發票，方可得到免費維修服務。(只需保留購買單據，無需登記。)

升級保用 : (須於購買本產品後10天內完成以下步驟；升級保用不適用於商業用途)

額外6個月保用: 到訪並" 追蹤" 本公司 (Origin Marketing Limited) 的Facebook，即可享有共18個月免費保用。(如果已追蹤，則自動享有此升級保用，毋須再進行上述步驟)。

服務中心
源澤市務有限公司
香港新界葵涌青山公路403號(近華星街12號)
匯城集團大廈21樓H室
www.origin.hk 電郵: info@origin.hk 電話: 2156 8238

www.origin.hk Find us on Instragarm

Warranty

Item : Ceramic Fan Heater

Model : FH9519K

This product is warranted for 1 year (commercial use for 3 months) from the date of purchase under the following conditions:

1.For any defect, in the judgment of our technician, if it is caused under normal use, we are responsible for repairing the product, and/or replacing parts at free of charge.
2.This warranty DOES NOT apply to:
   - If the product was damaged by abuse, misuse, negligence or accidents;
   - Repair, alteration/modification by unauthorized technician;
   - The housing, cover, rear grille, power cord & plug or accessories.
3. The customer is requested to bring the product to and from our Service Centre.
4. Any parts or accessories, which had been replaced, shall be of our property.
5. This warranty is valid in H.K.S.A.R. only.
6. Original invoice should be presented in order to get free service.(Simply keep the purchase receipt; no registrations required.)

Extended Warranty: (Complete following procedure within 10 days from the date of purchase. Extended warranty does not apply to commercial use)

Extra 6 months warranty: follow " Origin Marketing Limited " on Facebook to enjoy a total of 18 months of warranty. (If you have already followed, no need to do it again.)

Service Centre
ORIGIN MARKETING LIMITED
Unit H, 21/F., Reason Group Tower (nearby 12 Wah Sing Street), 403 Castle Peak Road, Kwai Chung, N.T., Hong Kong.
www.origin.hk Email: info@origin.hk Tel: 2156 8238

www.origin.hk Find us on Instragarm