global plug

Batus

SPEEDY CHARGE 20W QC3.0 PD3.0

Travel Adaptor User Manual



GaN Technology

Model: GP201W

*Please read the instruction manual carefully before use, and keep the instruction manual properly.
**This user manual can be acquired at www.batus.hk.

MODEL & SPECIFICATIONS

Product Name	Globalplug Adaptor 20W
Product Model	GP201W
Rating	100-250V~10A Max, 2500W Max
Input	100-250V~, 50-60Hz, 0.8A
USB-C1 Output	5.0V ⎓ 3.0A 15.0W, 9.0V ⎓ 2.22A 20.0W, 12.0V ⎓ 1.67A 20.0W
USB-C2 Output	5.0V ⎓ 3.0A 15.0W Max
USB-A1/A2 Output	5.0V ⎓ 2.4A Max per port
Multi Port Output	15.0V ⎓ 3.0A MAX
Total DC Output	20.0W
Product Size	60(W) X 85(H) X 55(D) mm (Approx.)
Accessories	User Manual

MAIN PARTS



The picture is for reference only, everything in kind shall prevail.

ATTENTIONS

1. This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety. Children should be supervised to ensure that they do not play with the product.
2. To prevent the risk of electric shock, DO NOT USE the set with broken charging cable, broken fuse or broken plug. All repair works must be made by a professional (authorized distributor). NEVER TRY TO REPAIR the cable or plug by yourself. Please take the damaged set to your local authorized maintenance center.
3. To prevent overloading and blowing fuses, ensure that no other high power appliance is plugged into the same socket, or another socket which is connected in the same circuit.
4. Adaptor (AC-AC) does not convert voltage.
5. Do not use with appliance requiring ground wire.
6. FOR used with unearthed appliance only.
7. This Adaptor is for temporary use only.
8. Unplug when not in use, Indoor use only.
9. Use this Product only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electrical shock or injury to persons.
10. Open the package and ensure that the Product is undamaged. In case of doubt, do not use the Product and contact your supplier.
11. Do not let children play parts of package.
12. Do not take this Product apart exposing electrical parts. Call customer service for assistance and guarantee information.
13. The Product is not intended for use in wet or damp locations. Never locate the Product where it may fall into a bathtub or other water container.
14. Do not place the Product near a source of heat or fire.
15. DO NOT OPERATE this Product near water sources or flammable liquids.
16. Please do not let water or other liquids flow into the interface of this product, causing damage to the product.
17. Avoid running high energy-consuming programs for a long time during use or charging;
18. The length of USB cable should be less than 3M.
19. If overheating occurs, please stop using it.
20. For Use Outside Hong Kong Only.
21. UK Pins Sealed According to HK Laws.
22. Refer to Manual to Unseal for Use Outside HK.

This product contains recyclable materials. Do not dispose this product as unsorted municipal waste. Please contact your local municipality for the nearest collection.

DIRECTIONS FOR USE

1. Plug the Adaptor into an AC powered socket.
2. Connect the USB cable to the Adaptor and yours devices.
3. After charging or using, remove the Adaptor from the power socket.
   Note: Due to regional restrictions, some features may not be available.
   Slide the switch to change plug types as shown:



USA	AUS	UK	EU
United States Japan Taiwan Thailand Canada	Australia China New Zealand	United Kingdom Singapore Malaysia	Austria Germany Korea Indonesia France Switzerland

Applicable in over 210 countries and regions.

The picture is for reference only, everything in kind shall prevail.

UNSEAL TO UK PLUG

Just cut the blockage, make sure there is no debris blocking the pins.

It can be used with a multitude of appliance up to 2500W at 250V or 1000W at 100V as shown:

USB port is suitable for this device as shown:

MAINTENANCE & CARE

WARNING: ALWAYS UNPLUG THE POWER PLUG BEFORE MOVING OR SERVICING. DO NOT IMMERSE THE ADAPTOR IN WATER! BEFORE CLEANING, MAKE SURE THAT THE UNIT HAS BEEN SWITCHED OFF AND IT IS UNPLUGGED FROM THE MAIN OUTLET.
House: Clean the outside of the Adaptor with a soft cloth, to remove persistent dirt or grime wipe down with a cloth that has been dampened with warm soapy water.
CAUTION: Do NOT use gasoline, benzene, thinner, harsh cleaners, etc., as they will damage the Adaptor. NEVER use ALCOHOL or any other SOLVENTS.
STORAGE: Store the Adaptor with these instructions in the original box in a cool and dry place.

TROUBLE SHOOTING

LED indicator does not light up:
1. Possible overload, unplug the device and check the LED indicator again.
2. Fuse burn-out, it cannot be replaced by yourself, please go to the service center for repair.

WARRANTY

This product is guaranteed for 1 year (commercial use for 3 months) from the date of receipt against manufacturing defect. The warranty does not cover the housing, USB-C cable and other accessories, damage or defect caused by negligence or use not according to this instruction manual.
Extended Warranty: (Complete following procedure within 10 days from the date of purchase. Extended warranty does not apply to commercial use)

A. Extra 3 months warranty: complete Online Warranty Registration on our website to enjoy a total of 15 months of warranty; or
B. Extra 6 months warranty: follow "Origin Marketing Limited"on Facebook to enjoy a total of 18 months of warranty. (If you have already followed, no need to do it again.)

Remark: For any repair service, please contact and bring with the invoice or receipt to the Service Centre.

Service Centre
ORIGIN MARKETING LIMITED
Unit H,21/F, Reason Group Tower (nearby 12 Wah Sing Street), 403 Castle Peak Road, Kwai Chung, N.T., Hong Kong.
Tel: (852) 2156 8238

Office Hours
10:30am - 12:30pm (Mon ~ Fri)
02:30pm - 05:30pm (Mon ~ Fri)
10:30am - 12:30pm (Sat)
(Closed on Sunday and Holiday)

www.batus.hk | Find us on | List of Applicable Countries/Regions

Origin Map


38
62K
荃灣西北線
Ping Lai Path Bus Stop
荃灣
荃灣西
荃灣西
荃灣西