




健康氣炸烤爐  
HEALTHY AIR FRYER



## AF7004 使用說明書 INSTRUCTION MANUAL

\*使用本產品前，請先細閱使用說明，並請妥善保存以便將來翻閱。

\*Read all instructions carefully before using this appliance, and keep this instruction for future reference when necessary.

## 重要安全提示

### Important Safety Information

健康氣炸烤爐  
Healthy Air Fryer



- 本機不是為體質、感覺或智力有障礙人士或8歲以下小孩或缺乏經驗及知識者使用，除非他們曾經接受負責安全人士的監督或指示，大人應指導小孩不可把玩電器。除非在負責安全人士的監督或指示，8歲以下小孩不可清潔及維護本機。

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.

- 本機不能用於附加外置的時計或控制器。  
Appliances are not intended to be operated by means of an external timer or separate remote-control system.
- 切勿將包含電器組件和加熱元件的外殼浸入水中，也不要在水龍頭下沖洗外殼。  
Never immerse the housing, which contains electrical components and the heating elements, in water nor rinse it under the tap.
- 在本機運行期間，請勿覆蓋進氣口和排氣口。  
Do not cover the air inlet and air outlet openings while the appliance is operating.
- 在熱空氣油炸過程中，熱蒸汽通過出氣口釋放。將手和臉與蒸汽和排氣口保持安全距離。從設備上取下配件時，還應注意防止熱蒸汽和空氣。  
During hot air frying, hot steam is released through the air outlet openings. Keep your hands and face at a safe distance from the steam and from the air outlet openings. Also be careful of hot steam and air when you remove the accessories from the appliance.
- 使用中的玻璃門表面會產生高溫。  
The glass window surface may get hot when the oven operating.

- 本機及其電源線應擺放於8歲以下小孩不能觸及的地方。

Keep the appliance and its cord out of reach of children less than 8 years.

- 如本產品的電源線有損壞痕跡，為保障安全，請立即停止使用並聯絡供應商更換。

If the supply cord is damaged, it must be replaced by manufacturer, its service agent or similar qualified persons in order to avoid a hazard.

- 請勿在炸籃、網籃、烤網及盛油盤中注油，否則可能引起火災。

Do not fill the frying basket, mesh basket, wire rack and grease tray with oil as this may cause a fire hazard.

- 使用過程中可觸及的表面可能會變熱。

The surfaces are liable to get hot during use.

- 切勿在本機運行時和使用後觸摸本機內部及其他配件。

Never touch the inside of the appliance and other accessories while it is operating and immediately after use.

- 不可在潮濕或有積水的環境使用，不可將本機放於浴缸或大型容器上面。

The Air Fryer is not intended for use in wet or damp locations. Never locate the Air Fryer where it may fall into a bathtub or other water container.



- 如果發現有黑煙從設備中冒出來，請立即將其拔下。從裝置中取出配件之前，請等待煙塵停止。

Immediately unplug the appliance if see dark smoke coming out of the appliance. Wait for the smoke emission to stop before you remove the accessories from the appliance.

## 重要安全提示

### Important Safety Information

健康氣炸烤爐

HEALTHY AIR FRYER

origo


- 打開包裝，檢查產品。如發現產品有損壞，請勿使用及即時聯絡供應商。  
Open the package and ensure that the appliance is undamaged. In case of doubt do not use the appliance and contact your supplier.

- 本產品不適用於室外及作工業用途。

This appliance is intended for household use ONLY and not for industrial or outdoor use.

- 使用本產品前，請確定規格標貼上所示的額定電壓與當地供電電壓相同。如有疑問可向供應商查詢。

Before using the appliance, check if the voltage marked on the rating label corresponds to the mains at your home.



- 本產品只可使用附設的電源線。

This product can only use with the attached power cord.

- 電源線切勿靠近火源，高溫或隱藏在地毯之下。

Do not put the power cord near fire, hot sources or under carpet.

- 切勿使用電源線把本產品掛起。

Never hang your appliance on the power cord.

- 切勿更換位於氣炸烤爐內部的LED燈。

The LED light located in the rear top cavity of Air Fryer can't be replaced.

- 選擇一個靠近電源插座的位置，但不要放在有水的地方使用。

Choose the near part of socket during use. Do not use it near any sources with water.

- 請使用獨立插座。不應使用萬能插頭或拖板或標稱小於13安培保險絲的插座。

Do not use extension cord. Always operate this roaster on the socket with at least 13A fuse.

- 氣炸烤爐應放於平穩、耐熱的表面上。

Please operate this Air Fryer on a flat and heat-resistant surface.

- 請勿將產品放在桌布或窗簾等可燃物料上或附近上使用。使用時不應靠近牆角，其周圍10cm內不應放置其他易燃物品，免溫度過高引起爆裂、變形、變色等。

In order to prevent any accident, do not place the appliance on or near combustible materials such as a tablecloth or curtains. Do not operate this Air Fryer near water sources or flammable liquids within 10cm.

- 當本產品打開或正在冷卻時，請將本產品及其電源線放在15歲以下兒童接觸不到的地方。


Keep the appliance and its mains cord out of the reach of children younger than 15 years when the appliance is switched on or is cooling down.


- 在清潔設備之前，讓氣炸烤爐冷卻約30分鐘。

Let the Air Fryer cool down for approximately 30 minutes before clean it.

- 在移動或清潔本產品前，必須先關掉本機及拔除電源插頭。


Always unplug before moving it and cleaning.

-  本產品含有可回收材料，不可把本產品作為未分類廢物。請聯繫當地就近指定回收點。

 This product contains recyclable materials. Do not dispose this product as unsorted municipal waste. Please contact your local municipality for the nearest collection.

## 各部名稱 Main Parts

健康氣炸烤爐  
HEALTHY AIR FRYER



## 使用方法 Operations

健康氣炸烤爐  
HEALTHY Air Fryer




氣炸烤爐可使用控制面板按鍵操控。

1. 取出所有包裝物料。
2. 用熱水，一些溫和清潔液和非研磨性海綿徹底清潔炸籃和其他配件。
3. 用濕布擦拭氣炸烤爐的內部和外部。

注意：這是一種可在熱空氣上工作的空氣炸爐，請勿在爐中注油或炸油脂。

4. 將氣炸烤爐擺放於穩固的平面上。
5. 把出風口隔牆板橫向放於出風口下方，使用兩枚螺絲將出風口隔牆板鎖緊於氣炸烤爐。



6. 打開玻璃門，將盛油盤放在氣炸烤爐內的下方。
7. 將食材放在所需烹飪配件裡，然後將所需烹飪配件正確放入氣炸烤爐內。  
注意：本氣炸烤爐帶有內置安全開關，只有將所需烹飪配件推進到正確的位置，才能將氣炸烤爐切換到待機模式。
8. 將插頭插入交流電壓220-240V~50/60Hz的獨立插座，氣炸烤爐已可使用。

The Air Fryer may be operated by the control panel.

1. Remove all packaging material.
2. Thoroughly clean the frying basket and other accessories with hot water, mild cleaner and a non-abrasive sponge.
3. Wipe the inside and outside of the Air Fryer with a moist cloth.  
Notice: This is an Air Fryer that works on hot air. Do not fill the Fryer with oil or frying fat.
4. Place the Air Fryer on a stable and flat surface.
5. Place the air outlet partition wall board horizontally below the air outlet, and use two screws to lock the air outlet partition wall board to the Air Fryer.
6. Place the grease tray at the bottom of the Air Fryer.
7. Put the ingredients in the required cooking accessories, and then put the required cooking accessories into the Air Fryer.  
Note: The appliance with built-in safety switch, only the cooking component propulsion in correct place, it can be switched to standby mode.
8. Plug the power plug into an 220-240V~ 50/60Hz electrical outlet, The Air Fryer is ready for use.

## 使用方法 Operations

健康氣炸烤爐  
HEALTHY Air Fryer




注意:

1. 切勿將氣炸烤爐放在非耐熱表面上。
2. 切勿在所有配件中注油或任何其他液體。
3. 切勿在氣炸烤爐頂部放置任何物品，這會擾亂氣流並影響熱空氣油炸的結果。
4. 放入炸籃或網籃中的食材不可超出"MAX"指示或超出附表中指示的數量(請參閱“設置”部分)，因為這可能會影響最終結果的質量。
5. 切勿在沒有配件的情況下使用氣炸烤爐。

Notice:


1. Never place the Air Fryer on non-heat-resistant surfaces.
2. Never fill all accessories with oil or any other liquid.
3. Never place any objects on top of the Air Fryer, this will interface with the airflow and affect the hot air frying result.
4. The ingredients placed in the frying basket or mesh basket must not exceed the "MAX" indicator or exceed the amount indicated in the table (see section 'Settings'), as this could affect the quality of the end result.
5. Never use the Air Fryer without the accessories in it.



1. 接通電源後，氣炸烤爐會“嗶”聲響起，控制面板閃爍，氣炸烤爐進入準備狀態。
1. When Air Fryer is plugged, the indicator on the control panel will flash with a "beep" sound.
2. 按開關鍵 "⏻"，顯示屏會顯示 "888"。按菜單鍵 "☰" 後可以透過此鍵選擇快捷菜單，也可以透過溫度鍵 "🌡️" 和時間鍵 "🕒" 手動設置煮食溫度及時間。
2. Press the On/Off Key "⏻", the display will show "888". Press the MENU Key "☰" to select a quick menu or press the TEMP Key "🌡️" and TIME Key "🕒" to manually set the cooking temperature and time.
3. 按開關鍵 "⏻" 開始/取消烤焗，氣炸烤爐內的LED燈亮起。
3. Press the On/Off Key "⏻" to start/cancel cooking, the LED lights in the Air Fryer are on.
4. 烹飪完成後，將在5聲“嗶”聲後關閉(僅顯示 "888")。
4. When the cooking is complete, it will be shut down after 5 "beep" sounds (only display "888").
5. 完成後，打開玻璃門，將配件從氣炸烤爐中拉出並將其放在耐熱表面上，小心地將食物從配件中倒到碟上。
5. After finished, open the glass door, pull the accessories out of the Air Fryer and place it on a heat-resistant surface, carefully pour the food out of the accessories onto plate.

### ● 炙烤 / Grilling

1. 這個功能是最適合用於燒雞翼和乾果等食物。  
1. This function is ideal for grilled chicken wings and dehydrate, etc.
2. 把烤網放進氣炸烤爐的最高位置，再把盛油盤放到最低位置。  
2. Insert the wire rack in the Air Fryer, then place the grease tray at the bottom of the Air Fryer.
3. 選擇合適的溫度及操作時間，按開關鍵"⏻"開始。  
3. Set the temperature and time at required temperature and cooking time; press On/Off Key "⏻" to start.
4. 如食物在設定時間前已完成熟透，可自行按開關鍵"⏻"取消。  
4. If cooking is completed before the end of the timer, please press the On/Off Key "⏻" to cancel.
5. 完成後，打開玻璃門，用耐熱手套將烤網從氣炸烤爐中拉出並將其放在耐熱表面上，小心地將食物從配件中倒到碟上。  
5. After finished, open the glass door, use the heat-resistant gloves to pull the wire rack out of the Air Fryer and place it on a heat-resistant surface, carefully pour the food out of the accessories onto plate.



### ● 旋轉式炙烤 / Grilling with the turnspit


1. 這個功能是最適合用於烤雞及其他肉類等食物。  
1. This function is ideal for grill chicken and other type of meats.
2. 先用旋轉燒烤叉把食物固定(如欲得到更佳效果，可用廚繩把食物扎緊)。  
2. Place the meat on the spit (for the best result, tie the meat by kitchen string)
3. 把盛油盤放到最低位置及把旋轉燒烤叉固定在氣炸烤爐中間位置。  
3. Place the grease tray to the bottom and the push the turnspit mount inside the Air Fryer.



4. 選擇合適的溫度及操作時間，按旋轉式炙烤鍵"🌀"及開關鍵"⏻"開始。  
4. Set the temperature and time at required temperature and cooking time; press the Rotisserie Key "🌀" and On/Off Key "⏻" to start.
5. 如食物在設定時間前已完成熟透，可自行按 "開關鍵" 圖標取消。  
5. If cooking is completed before the end of the timer, please press the "On/Off Key" to cancel.
6. 完成後，打開玻璃門，用燒烤叉把手將旋轉燒烤叉從氣炸烤爐中拉出並將其放在耐熱表面上，小心地將食物從配件中倒到碟上。  
6. After finished, open the glass door, use the split handle to pull the turnspit mount out of the Air Fryer and place it on a heat-resistant surface, carefully pour the food out of the accessories onto plate.


### ● 網籃 / Air Frying With Mesh Basket

1. 這個功能是最適合用於牛扒和曲奇等食物。  
1. This function is ideal for steak and cookie, etc.
2. 把網籃放進氣炸烤爐的最高位置，再把盛油盤放到最低位置。  
2. Insert the mesh basket in the Air Fryer, then place the grease tray at the bottom of the Air Fryer.
3. 選擇合適的溫度及操作時間，按開關鍵"⏻" 開始。  
3. Set the temperature and time at required temperature and cooking time; press On/Off Key"⏻" to start.
4. 如食物在設定時間前已完成熟透，可自行按開關鍵"⏻" 取消。  
4. If cooking is completed before the end of the timer, please press the On/Off Key"⏻" to cancel.
5. 完成後，打開玻璃門，用耐熱手套將網籃從氣炸烤爐中拉出並將其放在耐熱表面上，小心地將食物從配件中倒到碟上。  
5. After finished, open the glass door, use the heat-resistant gloves to pull the mesh basket out of the Air Fryer and place it on a heat-resistant surface, carefully pour the food out of the accessories onto plate.



### ● 炸籃 / Air Frying With Frying Basket

1. 這個功能是最適合用於薯條及爆米花等食物。  
1. This function is ideal for fries and popcorn, etc.
2. 先用炸籃手柄插入炸籃手柄連接槽把炸籃固定。  
2. Insert the frying basket handle into the Basket Handle's connection slot to fix the frying basket.
3. 把盛油盤放到最低位置，再把炸籃放進氣炸烤爐。  
3. Place the grease tray at the bottom of the Air Fryer, then insert the frying basket in the Air Fryer.
4. 選擇合適的溫度及操作時間，按開關鍵"⏻" 開始。  
4. Set the temperature and time at required temperature and cooking time; press the On/Off Key"⏻" to start.
5. 如食物在設定時間前已完成熟透，可自行按開關鍵"⏻" 取消。  
5. If cooking is completed before the end of the timer, please press the On/Off Key"⏻" to cancel.
6. 完成後，打開玻璃門，用炸籃手柄將炸籃從氣炸烤爐中拉出並將其放在耐熱表面上，小心地將食物從配件中倒到碟上。  
6. After finished, open the glass door, use the frying basket handle to pull the frying basket out of the Air Fryer and place it on a heat-resistant surface, carefully pour the food out of the accessories onto plate.





## 烘烤時間及溫度 Cooking Time & Temperature

健康氣炸烤爐  
HEALTHY Air Fryer



食品類別 Food	烹調時間(分鐘) Timer(Mins)	烹調溫度(°C) Temperature( °C)
薯條(Fries)	25	220
冷凍食品(Frozen Food)	10	80
雞翼(Wings)	15	200
乾果(Dehydrate)	480	70
牛扒(Steak)	12	180
薯片(Chips)	20	220
魚(Fish)	15	180
蔬菜(Vegetable)	12	180
爆米花(Popcorn)*	10	220
雞(Chicken)	30	220
蛋糕(Cake)	30	180
串燒(Skewer)	15	200
薄餅(Pizza)	15	180
保溫(Keep Warm)	30	80
多士(Toast)	4	200
曲奇(Cookies)	12	180

\*注意: 製作爆米花時需要將氣炸烤爐預熱2分鐘。

\*Note: When making popcorn need to preheat the Air Fryer for 2 minutes.

烹調時間及溫度需因應食物的重量及個人口味而作出調整，以上附表只供參考。

The cooking time and temperature are base on the quantity of food and cooking request. The above table is only for your reference.

## 烘烤時間及溫度

### Cooking Time & Temperature

健康氣炸烤爐  
HEALTHY Air Fryer




#### 設置烹飪時間和溫度

按菜單鍵 "⌂" 後，如果需要更改烹飪溫度和時間，只需按溫度鍵 "⬇️" 和時間鍵 "⌚" 即可手動選擇溫度和時間：

1. 按溫度鍵 "⬇️"，再按增加鍵 "⬆️" 和減少鍵 "⬇️" 可以一次增加或降低10°C 的烹調溫度。長按該按鍵將迅速改變溫度(溫度控制範圍：50°C - 220°C)。
2. 按時間鍵 "⌚"，再按增加鍵 "⬆️" 和減少鍵 "⬇️" 可以一次增加或減少烹飪時間，每次1分鐘。長按該按鍵將快速更改時間(時間控制範圍：1分鐘至60分鐘)。


注意："上方顯示為溫度，下方顯示為定時器。


- 氣炸烤爐內的LED燈亮起顯示加熱元件正在工作；當打開玻璃門時，它將會熄滅。
- 在烹飪過程中，如果玻璃門被打開，氣炸烤爐將會自動停止。此時，只能使用開關鍵 "⏻" 和旋轉式炙烤鍵 "，所有其他按鍵將被鎖定。關上玻璃門後，烹飪過程將會繼續。
- 在具有暫停功能的設備的工作狀態下打開玻璃門時，如果在30分鐘內未關上玻璃門，則氣炸烤爐進入關閉狀態，控制面板會變為黑屏。

#### Setting of cooking time and temperature

After pressing Menu Key "⌂", if you need to change the cooking temperature and time just simply press the Temp Key "⬇️" and Timer key "⌚" to manually select the temperature and time.:

1. Press Temp Key "⬇️", then presss "⬆️" key and "⬇️" key to increase or decrease cooking temperature (10°C at a time). Keeping the key held down will rapidly change the temperature(Temperature control range: 50°C-200°C).
2. Press Timer Key "⌚", then presss "⬆️" key and "⬇️" key to increase or decrease cooking time,(1 minute at a time). Keeping the key held down will rapidly change the time (Time control range: 1 min to 60 minutes).

Note: "The upper display shows the temperature, and the lower display shows the timer.

- The LED light in the Air Fryer shows that the heating element is working ; and it will disappear when the glass door is opened.
- If the glass door is opened during the cooking cycle, the Air Fryer will stop automatically. Only the ON/OFF Key "⏻" and Rotisserie " Key can be used during this point & all other keys will be locked. After closing the glass door, the cooking cycle will continue.
- When the glass door is opened under cooking condition, the Air Fryer will enter the pause function. If the door is not closed within 30 minutes, the Air Fryer will enter the closed state and the control panel will display a black screen.

## 烘烤時間及溫度

## Cooking Time & Temperature

健康氣炸烤爐  
HEALTHY Air Fryer



### 預約開機

1. 按菜單鍵 "⌂" 後可以透過此鍵選擇快捷菜單，或透過溫度鍵 "🌡️" 和時間鍵 "⌚" 手動設置煮食溫度及時間(參考第9頁)。
2. 再按預約開機鍵 "🕒"，屏幕將顯示默認保留時間1小時。再按增加鍵 "+" 和減少鍵 "-" 可以一次增加或減少預約時間，每次1分鐘。按住該按鍵將快速更改時間(長按會調整10分鐘)，(預設時間範圍是：1分鐘至9小時59分鐘)。
3. 要更改烹飪時間和溫度，請按菜單鍵 "⌂"，然後根據需要重置煮食溫度及時間。
4. 最後按開關鍵 "🔘" 確認設置，然後倒數計時器開始計時。  
注意: 要使用預約開機功能，必須按下菜單鍵 "⌂"，最後按預約開機鍵 "🕒" 進行操作。

### Preset Function

1. Press the Menu Key "⌂", to select a quick menu or press the TEMP Key "🌡️" and TIME Key "⌚" to manually set the cooking temperature and time (Refer to page 9).
2. Then press the Preset Key "🕒" and the screen will show the default reservation time of 1 hour. then press "+" key and "-" key to increase or decrease cooking time, (1 minute at a time), (long hold adjusts by 10 minutes). Keeping the key held down will rapidly change the time (Time control range: 1 min to 9 hours 59 minutes).
3. To change the cooking temperature and time, press the Menu Key "⌂" and reset the cooking temperature and time according to your requirement.
4. Finally press the ON/OFF Key "🔘" to confirm the setting and the countdown timer will begin.  
NOTE: To use the preset function, the Menu Key "⌂" must be pressed and then finally press the Preset Key "🕒" to operate.

注意: 如果按下菜單鍵 "⌂" 後一分鐘內未進行任何操作，本機將會自動關機。  
在烹飪過程中，請勿直接用手直接觸摸炸籃、網籃、烤網、旋轉燒烤叉和盛油盤。

Note: If no operation is performed within one minute after pressing the Menu Key "⌂", the Air Fryer will automatically shut down.  
During cooking, frying basket, mesh basket, wire rack, turnspit mount and grease tray are very hot, do not touch them directly by hand.

1. 燒雞翼  
Grilled Chicken Wings

材料: Ingredients:	做法: Steps:
雞中翼: Chicken mid-joint wings	1. 將雞翼解凍，洗淨，抹乾水分，加入醃料拌勻醃15分鐘。 Defroze chicken wings. Rinse and wipe dry. Marinate with mixed all the seasonings for 15 min.
調味料(雞翼): Seasonings(for chicken):	2. 將雞翼放於烤網上，然後把烤網放進氣炸烤爐的最高位置，再把盛油盤放到最低位置以160℃烤約10-15分鐘即成。  Place chicken wings on wire rack , then insert the wire rack in the Air Fryer, then place the grease tray at the bottom of the Air Fryer. Grill for 10 -15min at 160℃ and serve.
生抽 Light soya sauce 老抽 Dark soya sauce 糖 Suger 紹酒 Chinese cooking wine 胡椒粉 White pepper	貼士: Tips:  使用前，在盛油盤鋪上錫紙，容易清洗。 For easy cleaning, place a piece of foil at the bottom of the grease tray.

烹調時間及溫度需因應食物的重量及個人口味而作出調整，以上附表只供參考。  
The cooking time and temperature are base on the quantity of food and cooking request. The above table is only for your reference.

2. 自製薯條  
Home-made Fries

<p>材料: Ingredients:</p> <p>馬鈴薯: 300-800克 Potato: 300-800g</p>	<p>做法: Steps:</p> <ol style="list-style-type: none"><li>1. 將馬鈴薯去皮，切成條(8x8 毫米)。 Peel the potatoes and cut them into sticks(8x8 mm).</li><li>2. 將馬鈴薯在碗中浸泡至少30分鐘，將其取出並用廚房用紙擦乾。 Soak the potato sticks in a bowl for at least 30 minutes, take them out and dry them with kitchen paper.</li><li>3. 在碗中倒入1/2湯匙橄欖油，將薯條放在上面，混合直至薯條塗上油。 Pour 1/2 tablespoon of olive oil in a bowl, put the fries on top and mix until the fries are coated with oil.</li><li>4. 用手指或廚房用具從碗上取下薯條，以免多餘的油留在碗中。 Remove the fries from the bowl with your fingers or a kitchen utensil so that excess oil stays behind in the bowl.</li><li>5. 將薯條放於炸籃上，把盛油盤放到最低位置，再把炸籃放進氣炸烤爐以220°C炸約25分鐘即成。 Place fries on frying basket, then Place the grease tray at the bottom of the Air Fryer, then insert the Basket in the Air Fryer. Fry for 25min at 220°C and serve.</li></ol>
<p>調味料(馬鈴薯): Seasonings(for potato):</p> <p>橄欖油 Olive oil</p>	<p>貼士: Tips:</p> <p>請勿將薯條一次性從碗中傾倒入炸籃，以防止多餘的油滴在盛油盤底。 Do not tilt the bowl to put all the sticks in the frying basket in one go, to prevent excess oil from ending up on the bottom of the grease tray.</p>

烹調時間及溫度需因應食物的重量及個人口味而作出調整，以上附表只供參考。  
The cooking time and temperature are base on the quantity of food and cooking request. The above table is only for your reference.

## 清理及維護 Maintenance

健康氣炸烤爐  
HEALTHY Air Fryer



注意:

CAUTION:

警告: 不使用氣炸烤爐時, 經常保持拔除電源, 及切勿將氣炸烤爐浸於水或其他液體中。在清潔本氣炸烤爐前, 先將氣炸烤爐關掉及把電源線從插座拔出, 然後讓氣炸烤爐冷卻最少30分鐘。

\*注意: 打開玻璃門並卸下所有配件, 使氣炸烤爐冷卻更快。

WARNING: ALWAYS UNPLUG THE POWER CORD BEFORE MOVING OR SERVICING. DO NOT IMMERSE THE AIR FRYER IN WATER! BEFORE CLEANING, MAKE SURE THAT THE UNIT HAS BEEN SWITCHED OFF AND IT IS UNPLUGGED FROM THE MAIN OUTLET AND LET THE AIR FRYER COOL DOWN AT LEAST 30 MINUTES.

\* Note: Open the Glass Door and remove all accessories to let the Air Fryer cool down more quickly.

外殼: 清理時切勿將氣炸烤爐浸於水或其他液體中。使用濕潤軟布抹擦清潔, 頑固污垢可用軟布沾上含肥皂的溫水抹擦。

Housing: Clean the outside and grille of the Air Fryer with a soft cloth. To remove persistent dirt, wipe down with a cloth that has been dampened with warm soapy water.

1. 每次使用後都要清潔氣炸烤爐

1. Clean the Air Fryer each time .

2. 切勿使用研磨性、腐蝕性或易燃性清潔劑(例如漂白劑或酒精)清潔氣炸烤爐的任何部位。

2. Do NOT use abrasive, corrosive or flammable cleansers (such as bleach or alcohol) to clean any part of the Air Fryer.

3. 盛油盤、炸籃具有不粘塗層。請勿使用金屬廚房用具或研磨性清潔材料來清潔它們, 因為這可能會損壞不粘塗層。

3. The grease tray, frying basket of the Air Fryer have a non-stick coating. Do not use metal kitchen utensils or abrasive cleaning materials to clean them, as this may damage the non-stick coating.

4. 用濕布擦拭氣炸烤爐的外部。

4. Wipe the outside of the Air Fryer with a moist cloth.

5. 用熱水, 一些洗滌液和非研磨性海綿清潔所有配件。

5. Clean all accessories with hot water, mild cleaner and a non-abrasive sponge.

6. 用熱水和非研磨性海綿清潔氣炸烤爐內部。

6. Clean the inside of the Air Fryer with hot water and a non-abrasive sponge.

7. 用清潔刷清潔加熱元件, 以清除食物殘留物。

7. Clean the heating element with a cleaning brush to remove any food residues.

提示: 如果污垢粘在炸籃或盛油盤底上, 請在炸籃或盛油盤中註入一些清洗液。讓炸籃或盛油盤浸泡約10分鐘。

Tip: If dirt is stick to the frying basket or grease tray, fill the frying basket or grease tray with hot water and mild cleaner. Let the frying basket or grease tray soak for approximately 10 minutes.

儲存: 連同使用說明, 把氣炸烤爐存放於清涼及乾爽的地方。

STORAGE: Store the Air Fryer with these instructions in the original box in a cool and dry place.


## 技術規格 Specification

健康氣炸烤爐  
Healthy Air Fryer



型號 Model Number	AF7004
電源 Power Supply	220-240V~ 50-60Hz
額定功率 Rated Power	1600W
產品尺寸 Product Dimension	315 x 334 x 370 mm

## 源澤地圖 Origin Map



### 辦公時間

10:30am - 12:30pm (星期一至五)  
02:30pm - 05:30pm (星期一至五)  
10:30am - 12:30pm (星期六)  
(星期日及公眾假期休息)

### OFFICE HOURS

10:30am - 12:30pm (Mon to Fri)  
02:30pm - 05:30pm (Mon to Fri)  
10:30am - 12:30pm (Saturday)  
(Closed on Sunday and Holiday)

## 產品保用証(一年自攜服務)

健康氣炸烤爐  
Heathly Air Fryer



產品：健康氣炸烤爐

型號：AF7004

此產品由購買日期起計算，本公司將根據下列條款及細則，提供一年保養服務(商業用享為3個月)：

1. 於購買後一年內，經本公司技術員判斷為正常運作下損壞之產品，可獲免費維修和/或零件更換。
2. 以下情況不被包括在保養範圍內：
  - 若產品是因為濫用、錯誤使用、疏忽及/或意外而導致損壞；
  - 未經授權之自行處理、維修及/或改裝；
  - 任何機殼、面蓋、燒烤叉把手、旋轉燒烤叉、烤網、網籃、盛油盤、炸籃、炸籃手柄，以及配件。
3. 需要檢查或維修時，請將產品送往本公司服務中心，並於修理妥當後自行取回。
4. 更換後之任何損壞零件，均屬本公司所有。
5. 本保養服務只適用於香港特別行政區。
6. 顧客必須同時出示零售商之正式發票，方可得到免費維修服務。

\*\*\* 額外3個月保用：凡於購買產品後10天內完成網上登記，即可免費延長保用期3個月，即15個月免費保用(商業用途除外)。請即登入網站：[www.origo.hk](http://www.origo.hk)

### 服務中心

源澤市務有限公司

香港新界葵涌青山公路403號(近華星街12號)匯城集團大廈21樓H室

電話：2156 8238

[www.origo.hk](http://www.origo.hk)

[www.origo.hk](http://www.origo.hk)



Find us on



## Warranty Card(1 year carry-in)

Item : Heathly Air Fryer

Model : AF7004

This product is warranted for 1 year (commercial use for 3 months) from the date of purchase under the following conditions:

1. For any defect, in the judgment of our technician, if it is caused under normal use, we are responsible for repairing the product, and/or replacing parts at free of charge.
2. This warranty DOES NOT apply to:
  - If the product has been damaged through abuse, misuse, negligence or accidents;
  - Unauthorized repair, alteration/modification;
  - The housing, cover, split handle, turnspit mount, wire rack, mesh basket, grease tray, frying basket, frying basket handle or accessories, is excluded from this warranty.
3. The customer is requested to bring the unit to and from our Service Centre whenever service is needed.
4. Any defective parts, which had been replaced, shall be of our property.
5. This warranty is valid in H.K.S.A.R. only.
6. Please show the Invoice to get free service.

\*\*\*Extra 3 months warranty: just complete Online Warranty Registration within 10 days from the date of receipt, free warranty will be extended to 15 months (not applicable to commercial use). Please enter our website: [www.origo.hk](http://www.origo.hk)

### Service Centre

ORIGIN MARKETING LIMITED

Unit H, 21/F., Reason Group Tower (nearby 12 Wah Sing Street),  
403 Castle Peak Road, Kwai Chung, N.T., Hong Kong.

Tel: 2156 8238

[www.origo.hk](http://www.origo.hk)

[www.origo.hk](http://www.origo.hk)



Find us on

